

Rollenschneider  
Rotary Trimmer  
Coupeuse  
Rolsnijder  
Taglierina a lama rotante  
Cizalla de rodillo  
Роликовый резак  
Obcinarka krążkowa

IDEAL 0055

IDEAL 0075

IDEAL 0105



DE Betriebsanleitung  
EN Operating Instructions  
FR Mode d'emploi  
NL Gebruiksaanwijzing  
IT Manuale d'istruzione  
ES Instrucciones de uso  
RU Инсталляция  
PL Instrukcja obsługi



**Keine Bedienung durch Kinder!**

**Children must not operate the machine!**

**Pas d'utilisation par un enfant!**





**Bediening niet door kinderen!**

**Non lasciare utilizzare il tagliacarte a bambini!**

**No dejar que la utilicen los niños!**


**Не допускайте детей к пользованию аппаратом!**

**Dzieciom nie wolno obsługiwać urządzenia!**



## IDEAL 0105 U

- DE Aufbauanleitung • EN Installation • FR Montage • NL Installatie •
- IT Installazione • ES Instalación • RU Инсталляция • PL Instalacja



Krug & Priester GmbH & Co. KG  
 Simon-Schweitzer-Str. 34  
 D-72336 Balingen (Germany)

9700253 IDEAL 02-2014 11.12.2023 zm